

Installation Instructions for 05-09 Mustang Upper Replacement Grille

Tools Required:


Flat-head screw driver
Phillips-head screw driver
7mm wrench or socket (for optional Pony emblem)

Hardware Included:

14 – Screws	4 – Clamp tabs
14 – U nuts	2 – Long L tabs
4 – U tabs	2 – Short L tabs

Step 1:

Remove the six push tabs holding on the plastic upper radiator cover and remove it from the vehicle.




Step 2:

Remove the factory upper grille by pulling firmly and releasing it from the eight tabs that hold it to the front fascia. There are two on either side of the grille and four on the bottom lip.




Step 3:

Before the grille is completely removed from the vehicle, make sure to unplug the fog light harnesses and securely tie them to the radiator support so they do not make contact with the radiator itself.




Step 4:

If you have chosen to install the optional Pony emblem assemble the bracket to the emblem using the two provided tabs as shown below. Once emblem is secure to the bracket, use the supplied 7mm nut to secure the emblem and bracket assembly to the grille as shown. If you have chosen not to install the Pony emblem, please skip to Step 5.




Step 5:

Place four of the supplied U nuts onto the 90 degree side of the four supplied U tabs and insert them into the tabs of the front fascia as shown. (Note: Narrow U tabs must be placed on the outside tabs)

**Step 7:**

Place four U nuts onto outside of U tabs installed in Step 5. Remove two plastic fasteners from front radiator support, one holds a wiring harness and the other holds the hood release cable.

**Step 6:**

Install a clamp tab onto each of the U tabs and secure to bumper with supplied screws as shown.

**Step 8:**

Place two U nuts onto the slotted portions of the long L tabs. Using the supplied screws, mount the long L tabs in the holes vacated by the fasteners you removed in Step 7. Do not fully tighten the screws as you may need to adjust them during final installation of the grille. Install the removed fasteners into the provided holes in the long L tabs.



Step 9:

Place two U nuts onto the slotted portions of the short L tabs. Using supplied screws, mount the short L tabs to the inner holes of the grille as shown below. These will be used to reinstall your plastic factory radiator cover.

**Step 10:**

Complete installation of billet grille by using the final six supplied screws to secure it to the bracket you have installed in previous steps. When grille is properly aligned, fully tighten all screws on grille as well as the two screws holding the long L tabs to the upper radiator support. When grille is secure, reinstall the factory radiator cover using the six push tabs you removed in Step 1.

