



2015 Quarter Window Scoop

REQUIRED Alcohol Wipes
Adhesion Promoter

2 - Insert
1 - Tape Kit



1

Wipe the tape ledges on the louver and window glass with provided alcohol wipes followed by adhesion promoter. **Note: A clean surface is essential for proper adhesion.



2

Apply the Supplied tape as seen above.



3

Remove the tape backing from the insert and install the insert to the louver.



4

Fit the part before removing tape backing. The leading edge of the insert sits flush against the weather stripping. The top edge of the louver follows the indent on the window molding.



5

Remove tape backing. Line up the bottom, front, top edges and apply to glass.



6

Once placed, apply firm pressure over all tape surfaces.