



11-14 Billet Shift Knob

Step 1:

Spin your factory shift knob off (counter clockwise) and remove from boot.



Step 2:

Identify the proper adapter. The base of the factory shift knob will match the adapter.



Step 3:

Thread on the adapter as far as possible by hand.

Step 4:

Thread on the shift knob as far as possible, once threaded on, align the shift pattern by backing the shift boot adapter off to sit flush with the shift knob.



Step 5:

While holding the shift boot adapter, loosen and remove the shift knob. With the shift boot adapter held in place, tighten the 1/8" Allen set screw.

Step 6:

Thread on the shift knob and tighten the 3/32" Allen screw.

