



15-16 EcoBoost Blow Off Valve Adapter

Step 1:

Locate the factory turbo bypass valve. It is located on the turbo charge pipe located behind the coolant reservoir.



Step 2:

Remove the plug, and loosen the (3) 5mm allen bolts. Insert the bypass valve into the adapter flange, then reinstall the C&L adapter plate using the provided allen bolts.

