

Installation Instructions for Raxiom Reverse Light LED Conversion Kit (15-17 All)

Installation Time: 5 Minutes

Required Tools: None

Step 1: Locate your reverse light housing from underneath your car



Step 2: Rotate $\frac{1}{4}$ turn counter clockwise and remove from housing



Step 3: Replace factory bulb with new LED and re-install in reverse order



Installation is complete. Check for proper functionality. If the light does not illuminate, remove bulb and turn 180deg and re-install. Make sure all connections are tight.

Before/After



Installation Instructions Created and Submitted by AmericanMuscle customer, James B. – August 22nd 2016. Work completed on “Dorothy” his ’16 Mustang GT w/PP