

Installation Instructions for Raxiom Red LED Side Marker Light – Rear (15-16 all)

Installation Time: 15 minutes

Required Tools: Kneepads (optional)

PROECEDURE:

Step 1: Place hand behind fender closest to the wheel well and feel for the tab, press the tab back towards the rear of the vehicle.



Step 2: Pull out on the side closest to the tire and slide it towards the wheel until it comes free.



Step 3: Remove bulb/LED housing from the connector and plug in your new unit.



Step 4: Test your lights prior to inserting.



Step 5: Reinstall new light housings in reverse order from removal.



Installation Complete.



Installation Instructions Created and Submitted by AmericanMuscle customer, James B. - 7/25/16. Work completed on "Dorothy" his '16 Mustang GT w/PP