

## 15-16 Quarter Window Louver

REQUIRED Alcohol Wipes      Tape Kit  
 Adhesion Promoter



1  
 Wipe the tape edges on the Scoop and window glass with provided alcohol wipes followed by adhesion promoter. \*\*Note: A clean surface is essential for proper adhesion



2  
 Apply the supplied tape as seen above.



3  
 Test fit the louver and note how the louver fits to the window. Then remove tape backing, apply the louver to the window using firm even pressure.