

## **ENG-015-333**

2015-2016 Mustang CPC Coolant Tank Reservoir Cover Made in U.S.A.

\*\* Please Read entire instructions before attempting to install this product. Failure to do so could result in damage to the product which could void the product warranty. \*\*

This is an easy installation and will not require the removal of your coolant tank.

## **Tools Required:**

**Pliers** 

\*\*\*\*

10mm socket

Ratchet

- 1. DO NOT install cover while engine is hot.
- 2. Remove coolant tank cap cautiously as it may be under pressure.
- 3. Remove only the two top front and back coolant hoses that attach to coolant tank.
- 4. Remove the two front mounting bolts and store away, this cover comes with new mounting hardware.
- 5. Put the cover over and through the front stem barb and slide the cover over the rear stem barb through the slot in cover and push cover down.
- 6. Reinstall tank cap
- 7. Now that the cover is in place reinstall both top coolant hoses, make sure to push hoses THROUGH the holes of the cover and all the way into the tank to insure proper clamping.
- 8. Install the two supplied bolt to the front mounting points.
- 9. Double check cap and hoses are properly attached and secure.

## Congratulations your installation is complete!

If any you have any questions or need assistance, please call our toll free number (888) 225-7669 8:00 a.m. - 4:30 p.m. Fri-7:00 a.m.-3:30 p.m. PST and ask for Tech help

