

10-14 Battery Cover

REQUIRED Flat Screw Driver



1 Remove the (2) Plastic factory cowl screw clips. Clean the velcro mounting surface on the fender (dashed line above).



2 Cut the supplied velcro to length. Clean the mounting surface with the supplied alcohol wipe. Allow the part to dry. Then apply the velcro strip. Peel the adhesive backing off the velcro.



3 Position the part on the car so that the (2) mounting holes line up. Using the supplied push pins, install the battery cover. Then apply firm even pressure to the velcro to ensure proper adhesion.

Master Cylinder Cover



1 Remove the (2) Plastic factory cowl screw clips. Remove the clip holding the hood latch cable to the fender. Clean the velcro mounting surface on the fender (dashed line above).



2 Cut the supplied velcro to length. Clean the mounting surface with the supplied alcohol wipe. Allow the part to dry. Then apply the velcro strips. Peel the adhesive backing off the velcro.



3 Position the part on the car so that the (2) mounting holes line up. Using the supplied push pins, install the battery cover. Place the hood latch cable in the notch. Then apply firm even pressure to the velcro to ensure proper adhesion.