

393723 393724
393725 393726



15-16 MMD Carbon Fiber Covers



Apply the supplied tape as seen above.



Apply the supplied tape as seen above.



Apply the supplied tape as seen above.



Apply the supplied tape as seen above.



Thoroughly clean the vehicle's paint/plastic ensuring it is wax and grease free. Then peel the tape backing off and install.



Thoroughly clean the vehicle's paint/plastic ensuring it is wax and grease free. Then peel the tape backing off and install.



Thoroughly clean the vehicle's paint/plastic ensuring it is wax and grease free. Then peel the tape backing off and install.



Thoroughly clean the vehicle's paint/plastic ensuring it is wax and grease free. Then peel the tape backing off and install.