

15-17 Paddle Shifter Extensions

REQUIRED Alcohol Wipes

Adhesion Promoter



Clean the paddle extension with the supplied alcohol wipe allow time to flash dry Then peel back the adhesive backing and apply the double sided tape to paddle extension.



Clean the mounting surfaces with the supplied alcohol, allow time to flash dry.



Peel back the adhesive backing. Line the extension up with the factory paddle shifter.



Apply firm pressure to the paddle and paddle extension to ensure proper adhesion.