

# **Chrome Strut Tower Cap Cover Set (05-10 All)**

**Time Required:** 15min

**Tools Required:**

✓ Scissors



**Safety:**

- (1) Engage Emergency Brake or insure in Park for Automatics.
- (2) Make sure engine is off and cool.

**Preparation and Install:**

- (1) Open Hood and Clean Strut Tower.



**(2) Insure Strut Covers are clean prior to applying Butle Tape. (Note: Trial fit Strut Covers to insure proper fit prior to applying Butle Tape)**



**(3) Cut Butle Tape into 8 equal sizes.**



**(4) Apply Butle Tape based on Trial Fit where contact with Strut Tower occurs.**



**(5) Install**





**(6) Passenger Side Install Complete**



**(7) Driver Side Install Complete**



**Installation Instructions written by AmericanMuscle Customer Mitch Smith 07.04.14**