
1984 - 1989 Mustang 5.0

Radiator Reservoir Cap Chrome Cover

The chrome-plated radiator reservoir cap chrome cover simply slips over the existing original cap.

INSTALLATION INSTRUCTIONS - Be sure your engine is off and cool. Carefully clean and dry your original cover. Simply slip the new cover onto your original cap. No tape is needed.

Since this chrome cover is made in metal, you can use a damp cloth or chrome polish to clean and shine it when necessary.

