

MODERN BILLET

Oil DipStick Handle 2015-2017



Remove the dipstick from the vehicle. Using an appropriate sized punch or drill bit, tap out the factory roll pin.



Remove the dipstick from the factory handle and slide it into the Modern Billet Chrome handle.



Re-install the factory roll pin in the Modern Billet handle.