

# MODERN BILLET

## 5-Speed Shift Knob 2005-2010

384343  
384345  
384344  
41066  
41065  
41141  
102256  
41140  
102255  
41431  
41441  
41432  
41440



Remove the factory shift knob by rotating it counter clockwise. The shift boot is held onto the shift knob with tension, gently pull the off the factory shift knob



Install the supplied shift boot retainer. Thread the retainer on as far as it will go. Pull the shift boot onto the groove of the retainer.



Then thread the shift knob on until it stops. Back the shift knob off so that the shift pattern is aligned properly. Then turn the retainer counter clockwise until it locks against the shift knob.