

SR Intake Installation Instructions (94-95 GT)

Tools Required:

- 10mm Socket
- 10mm wrench
- Flathead screwdriver



Step 1. Remove your factory intake, MAF sensor and IAT sensor from your vehicle. The IAT sensor and MAF sensor housing will need to be reused in the new intake assembly.



Step 2. Install the MAF sensor onto the lower portion of the intake tube then install the heat shield and filter onto the tube.



Step 3. Place the lower portion of the intake into the fender well and secure it to the vehicle using the factory mounting points.



Step 4. Screw the factory IAT sensor into the new upper intake tube



Step 5. Install the upper portion of the intake onto the vehicle, ensuring all connections are plugged in and tight before driving the vehicle.