

AMERICANMUSCLE PRE-PAINTED PARTS

Installation instructions for Painted Radiator Extension Covers (05-09 Mustang)

Step 1

Open the hood and remove the 10mm upper bumper cover bolt as shown on both the driver & passenger side of the vehicle.



Step 2

Slide the driver's side extension under the center radiator cover as shown. Once in place, use the supplied new 10mm bolt to secure the extension to the upper bumper cover.



Step 3

If your car has hood struts, skip to Step 4. If you still have the factory prop rod, have someone hold the hood open for this step. Slide the passenger side extension over the factory prop rod using the provided hole as shown.



Step 4

Slide the extension under the center radiator cover as you did for the driver's side. Once in place, use the supplied new 10mm bolt to secure the extension cover. This completes the installation of your Painted Radiator Extension Covers from American Muscle.

