

MODERN BILLET

Chrome Under Hood Dress Up Kit 2011-2014



Oil Cap Installation: Remove the factory oil cap by turning it counter-clockwise. Then Install the Modern Billet Chrome Oil Cap.



Brake Fluid Reservoir Cap: Using the supplied alcohol wipe, clean the reservoir cap. Ensure the cap is tight. Test Fit the Modern Billet cap. Loosen the set Allen screw(s). Remove the double sided tape backing, place the cap over the reservoir and tighten the set screw(s).



Windshield Reservoir: Remove the factory reservoir cap. Wrap the cable tether around the reservoir opening then press the cap onto the reservoir.



Radiator Cap Cover: Using the supplied alcohol wipe, clean the reservoir cap. Ensure the cap is tight. Test Fit the Modern Billet cap. Loosen the set Allen screw(s). Remove the double sided tape backing, place the cap over the reservoir and tighten the set screw(s).