AMERICAN MUSCHE PRE-PAINTED PARTS

Installation Instructions for Painted Arm Rest Cover (05-09 Mustang)

Step 1

Clean your center console door with a non-oil based interior cleaner. Use the supplied alcohol pad to thoroughly wipe down the outside edges where the adhesive tape will attach.

Step 2

Turn the painted console cover upside down and remove the backing from the adhesive tape as shown.

Step 3

Place the cover over the console door making sure that it is correctly aligned and even with the front edge of the door. Once the cover is properly aligned over the door, firmly press down on the edges of the cover to fully seat the adhesive tape. This completes the installation of your Painted Console Cover from American Muscle.





