

2013 Grille Blackout



Be sure to thoroughly clean the front grille surround before beginning installation. This will help the adhesive tape to adhere properly.

Contents:

- (1) - Grille Blackout
- (2) - Alcohol Prep Pad

1



Using the supplied alcohol prep pad, thoroughly wipe down the area of the front bumper surround to which the grille blackout will adhere.

3a



Beginning with either side of the bumper, place the blackout flush up against the headlight, making sure that the front edge is flush with the grille.

2



Peel the back from the 3M Adhesive Tape as shown.

3b



3



Once the part is properly aligned, press down firmly to fully seat the tape.