

2010-2012 Emblem Cover



Before beginning, be sure to thoroughly clean the emblem and area around the emblem on the rear decklid. This will ensure the adhesive tape adheres properly.

1



Using the supplied alcohol prep pad, thoroughly wipe down the chrome plated area of the emblem where the cover will adhere.

3



Install the cover over the emblem as shown, making sure the thicker wall (marked by a green line) of the cover is at the top. Once the cover is properly aligned, press down firmly around the edges to fully seat the tape.

Contents:

- (1) - Emblem Cover
- (1) - Alcohol Prep Pad

2



Remove the tape backing by pulling on the small tab as shown.

MMD
MODULAR MUSCLE DESIGN