

Modern Billet Chrome Dash Button Bezel (05-09 All)

Time Required: 15 min

Tools Required: None



Safety:

- (1) Engage Emergency Brake or insure in Park for Automatics.

Preparation and Install:

- (1) Thoroughly clean the perimeter of the dash buttons. Remove the 3M tape and install.



(2) Press firmly all around the bezel and hold for 30 seconds.



Complete

Before



After



Installation Instructions written by AmericanMuscle Customer Mitch Smith 10.19.14