

2011-2014 Mustang GT Throttle Body Spacer Installation

1. Remove your engine cover (if equipped)
2. Remove the factory or aftermarket cold air intake



3. Using an 8mm socket, remove the 4 bolts holding the throttle body to the intake manifold



4. Place the supplied gasket between the throttle body and the spacer.



5. Using the supplied longer hardware, reinstall the throttle body, throttle body spacer assembly.



6. Tighten all bolts to factory specification and reinstall the intake and engine cover.