

# MODERN BILLET

## Chrome Under Hood Dress Up Kit 2005-2009



**Oil Cap Installation:** Remove the factory oil cap by turning it counter-clockwise. Then Install the Modern Billet Chrome Oil Cap.



**Brake Fluid Reservoir Cap:** Using the supplied alcohol wipe, clean the reservoir cap. Ensure the cap is tight. Test Fit the Modern Billet cap. Loosen the set Allen screw(s). Remove the double sided tape backing, place the cap over the reservoir and tighten the set screw(s).



**Windshield Reservoir / Power Steering Cap:** Remove the factory reservoir cap. Wrap the cable tether around the reservoir opening then press the cap onto the reservoir.



**Radiator Cap Cover:** Using the supplied alcohol wipe, clean the reservoir cap. Ensure the cap is tight. Test Fit the Modern Billet cap. Loosen the set Allen screw(s). Remove the double sided tape backing, place the cap over the reservoir and tighten the set screw(s).

## Oil DipStick Handle 2005-2009



Remove the dipstick from the vehicle. Using an appropriate sized punch or drill bit, tap out the factory roll pin.



Remove the dipstick from the factory handle and slide it into the Modern Billet Chrome handle.



Re-install the factory roll pin in the Modern Billet handle.