

## Modern Billet Chrome Oil Dipstick Handle (05-14 V6)

### Tools Required:

- Hand Saw
- Razor Blade
- 5/32 Drill Bit and Drill
- Allen Key Set
- Ruler



**STEP 1.** Measure from the base of the dipstick handle up 5/8" and mark the handle for cutting.



**STEP 2.** Using a small hand saw, cut the top of the handle off where you previously marked it and trim the sides to be square in shape.



**STEP 3.** Using the handle for reference, mark the factory handle for drilling.



**STEP 4.** Using a 5/32 drill bit, drill a hole for the retaining screw to pass through.



**STEP 5.** Slide the t-handle over the factory handle and insert the retaining screw into place to hold the two halves together.