



Chrome Fuse Box Cover 2005-2009



Begin by test fitting the chrome fuse box cover.



Thoroughly clean the top of the fuse box so that it is free of any grease/oil. Then wipe the plastic down with an alcohol wipe. Remove the tape backing.



Apply the fuse box cover applying firm even pressure to ensure proper adhesion.