

Installation Instructions for Door Sill Plates (94-04 Mustang)

Step 1:

Remove the inner plastic factory trim by pulling up as shown.



Step 2:

Remove the outer plastic factory trim by prying gently with a plastic scraper or similar.



Step 3:

Thoroughly clean the surface where the outer trim was attached, removing the left over adhesive.

Step 4:

With the surface clean, wipe down the area with the supplied alcohol prep pads. Remove the backing from the 3M tape on the new sills and place them on the door sill as shown. Press down firmly to fully seat the adhesive.



Step 5:

Replace the factory plastic inner trim to complete the installation.