



FLEX LINES

WARNING

ALWAYS CHECK FOR BINDING AND CLEARANCE

- After installation, check brake lines at full steering lock left and right. Lines must have sufficient length so as not to bind over full suspension travel.
- Lines must be supported and routed to ensure there is no interference with any part of the vehicle or suspension, and must not rub on any moving parts (suspension, wheels, or other components).
- Vehicle manufacturers make many variations of most vehicles, and many vehicles have been modified. These lines may not be fit for a particular application. If you are not sure, do not use them.
- Check for abrasion and damage after testing brakes per minimum test procedure (see other side of card).
- Read the back of this card as well as all warnings contained within the flex line packaging.