

FOR HID HEADLIGHTS ONLY

Step 1:

Using a T20 Torx Head Bit, remove the factory HID Ballast as shown. Be sure to unplug both connectors to completely remove the ballast.



Step 2:

Remove the plastic bulb cover and the HID bulb (Be very careful not to touch the actual bulb once removed)



Step 3:

Remove the harness from the bulb and install it into the new housing by removing the Phillips head screw and bending the tab back as shown.



Step 4:

Once the bulb is secured in the new housing, plug the harness back into the bulb and route it through the housing. Plug both connectors back into the ballast and use the original Torx screws to install it on the new housing along with the black plastic protective cover.

