

Ford Racing High Performance 9mm Spark Plug Wires – Blue (96-98 Cobra)

Time Required:

Aprox. 1 hour.

Tools Required:

- ✓ Socket wrench
- ✓ 8mm socket
- ✓ 11mm socket
- ✓ Flat head screwdriver



1: Remove strut tower brace, if equipped.

2: Remove vacuum hoses from intake tube. There is one on the front and one on the back.

NOTE: My car no longer has a vacuum hose connected in the rear position. In the picture, there is a red plug where your vacuum hose will be located.





3: Disconnect IAT sensor.



4: Loosen ring clamps using an 8mm socket and remove intake tube.





5: Using an 11mm socket, remove the 4 nuts holding the spark plug wire cover onto the valve cover, and remove the spark plug wire cover.



6: Remove the old plug wires.



7: Remove the wires from the ignition coils.



Repeat steps 5-7 on other side

8: Install new Ford Racing plug wires. Note that each wire is labeled with its cylinder number. Look at the image below for wire locations.



9: Reinstall spark plug wire covers.

10: Reinstall intake tube.

11: Reconnect IAT sensor and vacuum hoses.

12: Reinstall strut tower brace if equipped.

Congratulations, you're done!



Installation Instructions Written by AmericanMuscle Customer Kevin Cross 1.30.2014