

## Quarter Light Trim - Chrome (05-09 All)

**Time Required:** 15min

**Tools Required:**

- (1) Alcohol Prep Pad (Included)
- (2) Cleaning Cloth



**Safety:**

- (1) Engage Emergency Brake or insure in Park for Automatics.

**Preparation and Install:**

- (1) Thoroughly clean your Quarter Lights with the cleaning cloth and Alcohol Prep Pad. (Note: Ideal conditions for Trim adhesion are at a temperature of ~70F or ~20C and out of direct sunlight)



**(2) Remove all the 3M tape.**



**(3) Use two hands to align the trim to edges of the light and then press firmly in.**



**(4) Firmly apply pressure all around the trim and then allow to set ~6 hours at ~70F or ~20C.**



## Complete

**Before**



**After**



Installation Instructions written by AmericanMuscle Customer Mitch Smith 8.19.2014