2011-2014 Ford Mustang GT 5.0L

2-3/4" After Cat X-Pipe

Part #1460



Special Tools

Install Time:

Required:

Approximately
1 Hour

 No special tools required

Difficulty:

2 out of 5

Follow these instructions carefully to ensure correct fitment and operation.

STEP 1

 Disconnect the negative battery terminal. Raise the vehicle up and safely support it.

STEP 2

 Loosen barrel style clamps at the rear of the stock H-Pipe section. Support rear exhaust pipe sections behind H-pipe sections. Loosen the clamps at the front of the H-Pipe section where it connects to the catalytic converter pipes. Now remove the stock H-Pipe Section.

STEP 3

 With a flat head screwdriver, lift the locking tab on the barrel clamps and remove from the H-Pipe. Slide the barrel clamps back onto the stock exhaust pipes.

STEP 4

 Lift the BBK X-Pipe section into place and connect to the barrel clamps first.

STEP 5

 Position the front of the BBK X-Pipe to make the connection to the catalytic converter pipes. You will have to unscrew the clamps all the way out. Position the front of the BBK X-Pipe up against the round end of the catalytic converter pipes to make the connection. Position the clamps in place and tighten the clamps enough to hold.

STEP 6

 Check the position of the exhaust system and make any adjustments up or down. When satisfied with the exhaust system placement, tighten the barrel style clamps.

STEP 7

 Now tighten all the clamps starting from the front of the car.

STEP 8

Reconnect the negative battery terminal and start the engine to check for leaks. Sometimes the connection at the catalytic converter pipes can be a bit tricky to get sealed. If you are having trouble with a leak there, just barely loosen the barrel style clamps and loosen the front clamps again to pull the X-Pipe up to the converter pipes, and then re-tighten the front clamps first, then the rear barrel style clamps.



Join our Facebook page www.facebook.com/bbkperformance





Check us out on Youtube www.youtube.com/bbkperformance

WWW.BBKPERFORMANCE.COM

▼) †

For any questions, email us: tech@bbkperformance.com

installation instructions

