



**2011 FORD 5.0L COYOTE  
SWAP X-PIPES  
FOR USE WITH 1643/0 HEADERS  
PART#'s 1786 (with Cats)  
1787 (Off Road)**

**INSTALLATION INSTRUCTIONS**

***These X-pipes are designed to be used with BBK's  
Coyote Swap Headers # 1634 (chrome) 16340 (polish ceramic)***

- STEP 1** With vehicle raised in the air and supported on jackstands, pre-install the BBK Coyote Swap Headers and the supplied studs into the headers collectors.
- STEP 2** Lift X-pipe assembly into place and support with a jack. Connect the front flanges of the X-pipe to the header collectors. Slide X-pipe flanges over the header collector studs.
- STEP 4** Install the nuts and washers, provided with the headers, onto the collector studs.
- STEP 5** Connect the rear of the X-pipe to the stock flow tubes going to the mufflers.
- STEP 6** Position X-pipe for best fit and ground clearance and tighten all nuts and bolts.



**W W W . B B K P E R F O R M A N C E . c o m**

**CLICK TO VISIT**

**IMPORTANT-** All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle. BBK Performance Inc. accepts no responsibility for injuries or damage caused by or during the installation of this product.