



Part # 1636,1637- 2005-10 Ford Mustang GT
 Part # 16515,1851- 2005-12 Ford Mustang GT500

X-Pipe for Full Length Headers



Special Tools
 Required:

- No special tools required

Install Time:
 Approximately
 30 mins

Difficulty:
 2 out of 5

Follow these instructions carefully to ensure correct fitment and operation.

STEP 1

- Disconnect the negative battery terminal.

STEP 2

- With BBK Full Length Headers # 1641, 16410 or 16495 installed, lift the BBK X-Pipe into place.

STEP 3

- Line up the rear of the X-Pipe with the stock barrel style clamps and slip the clamps over the reduced end of the X-Pipe.

STEP 4

- Position the X-Pipe collector flanges up to the headers, connect the X-Pipe with the studs provided in the header kit installed into the header collector flanges. Slide studs thru the holes in the X-Pipe flanges and install nuts and washers.

STEP 5 STEP 6

- Adjust position of exhaust system for fitment and clearance. Tighten barrel style clamps and collector nuts.

STEP 7

- Connect the supplied oxygen sensor extensions to the sensor and the wire harness at the transmission.

STEP 8

- Reconnect the battery and start the engine and listen for any leaks.

Hardware Included

- 1676
 - CHD241 18" Oxygen Sensor Extension (2pcs)



Join our Facebook page
www.facebook.com/bbkperformance



Follow us on Twitter
 @bbkperformance



Check us out on Youtube
www.youtube.com/bbkperformance

WWW.BBKPERFORMANCE.COM

For any questions, email us:
tech@bbkperformance.com

installation instructions

1

IMPORTANT: All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle. BBK Performance Inc. accepts no responsibility for injuries or damage caused by or during the installation of this product.