Part # 1515,15150- 1986-93 Ford Mustang 5.0L Part # 1525,15250- 1994-95 Ford Mustang 5.0L Part # 1511,15110- 1979-93 351 Windsor Mustang Swap

# **BBK Shorty Headers**



Special Tools

Required:

 No special tools required **Install Time:** 

Approximately 2 Hours

Difficulty:

3 out of 5

Follow these instructions carefully to ensure correct fitment and operation.

## STEP 1

Disconnect the negative battery terminal.

#### STEP 2

 Remove the entire stock air inlet system from the vehicle, this is easily done by removing the hose clamp at the throttle body, the two massair mounting bracket bolts from the strut tower/inner fender well area, and the two filter box mounting nuts at the top edge of the factory box.

# STEP 3

 Remove the air injection tubes from the passenger side. <u>NOTE!!!</u> On 1994-1995 models, remove the steel EGR Tube mounted on the passenger side header, kit 1525 and 15250 include a new EGR Tube Assembly.

## STEP 4

 Remove the spark plugs and spark plug wires from the vehicle.

# STEP 5

 Working from under the vehicle, remove the nuts connecting the H-Pipes to the factory exhaust manifolds and the nuts holding the mufflers to the H-Pipe and slide back a few inches for clearance.

#### STEP 6

 Remove the stock exhaust manifolds and clean any gasket material from the heads. (Header removal and installation is done at the top of the engine compartment).

## STEP 7

 Using the gaskets provided start all the new header bolts before tightening the new headers.

#### STEP 8

 Reverse the previous steps to complete the installation.



Join our Facebook page www.facebook.com/bbkperformance





Check us out on Youtube www.youtube.com/bbkperformance

WWW.BBKPERFORMANCE.COM

•

For any questions, email us: tech@bbkperformance.com

installation instruction

