



**P/N S197-530 Made in USA**

## **2005-09 Tru-Billet Emergency Brake Handle Installation Instructions**

Thank you for your purchase of SilverHorse Racing products. Please read all directions before beginning the installation. A factory shop manual should be available for reference during installation. If, after reading these and any accompanying directions, you feel that you may not be able to complete the installation safely and properly, please seek out professional installation by certified technicians. Please read and understand our product purchase agreement (included) prior to starting installation. Vehicle should be off with key removed from ignition and in park with parking brake set prior to beginning installation. Expected installation time is 5 minutes.

### **TOOLS / MATERIALS REQUIRED:**

Allen Wrench (included)	Safety glasses (please wear at all times during installation)
-------------------------	---

1. Turn key to the off position and remove from ignition, making sure vehicle is in park / neutral and the parking brake is set on a flat, level surface.

2. Slide new cover over existing E-Brake, being careful not to accidentally release brake. Flat end goes toward the back, with angled end toward the front, and set screws to the bottom. Use included Allen wrench to tighten set screws snug in bottom, but over-tightening is not required and will just dig into rubber handle. Set screws may need to be backed out slightly for installation, as they are fully threaded into holes here at SilverHorse Racing.

3. Enjoy your new E-Brake !!

**If you have any questions, feel free to contact us at the number listed below or via email.**

**Tech Questions: (321)-722-2813.**

**Email us -**

**[Tech@SilverHorseRacing.com](mailto:Tech@SilverHorseRacing.com)**

**“If it’s not good enough for our cars, we won’t make it for yours.”**



**MEMBER**