



P/N S197-540 Made in USA

2005-09 Tru-Billet Replacement Door Switch Plate Installation Instructions

Thank you for your purchase of SilverHorse Racing products. Please read all directions before beginning the installation. A factory shop manual should be available for reference during installation. If, after reading these and any accompanying directions, you feel that you may not be able to complete the installation safely and properly, please seek out professional installation by certified technicians. Please read and understand our product purchase agreement (included) prior to starting installation. Vehicle should be off with key removed from ignition and in park with parking brake set prior to beginning installation. Expected installation time is 10 minutes.



TOOLS / MATERIALS REQUIRED:

Small, Flat blade screwdriver

Safety glasses (please wear at all times during installation)

Large pliers (optional)

1. Turn key to the off position and remove from ignition, making sure vehicle is in park / neutral and the parking brake is set on a flat, level surface.
2. Starting with the driver's side, grasp the original switch plate and the section below it. They will unclip from the door panel as an assembly. See photo. Flip the piece over to expose the switch (there are two on the convertible) and unclip the factory wiring from the switch(es).



3. Using your fingers, push on the two clips retaining the switch plate to the lower cover. This will release the original switch plate from the cover.
4. Using the small screwdriver, walk the power window switch(es) out of the original cover.

