

How to install 2010-2013 Painted Mirror Covers

Tool's required: None, but wear gloves though if you're worried about scratching the nicely painted surface of your mirror covers.



Installation Instructions:

1. Approach either the driver's side or passenger side mirror of your 2010+Ford mustang.
2. Grab the edge of the mirror cover that is towards the glass.



3. Using both hands apply firm pressure pulling into your body and up at the same time. *These mirror covers are held in by one large push in snap lock type connector. By pulling towards you and up at the same time you will pop this connector off.*

4. After removing the stock ugly black plastic mirror cover turn it over. You will see the connector I am talking about pay attention to the location of that connector.



5. With the correct cover approach side of car to be replaced, slide the one large connector into the slot on the mirror housing.
6. Once it clicks into place then press down and in all around the mirror housing the other smaller alignment pieces will then pop into place.



7. And that's it your done stand back and admire your work and how easy it was to rid yourself of those ugly plastic mirror covers!



Installation instructions provided by AmericanMuscle customer Benjamin Olds 8.9.12