

Antenna Cover

2005-2013

MMD
MODULAR MUSCLE DESIGN

! Note: Be sure to thoroughly clean the area of the decklid around the antenna to ensure good adhesion of the 3M tape.

1



Clean the area around the factory antenna thoroughly with the supplied alcohol prep pad.

2



Remove the backing from the 3M tape on the back side of the cover as shown.

3



Be sure to center the cover over the factory antenna and place it on the decklid. Once the cover is properly located, firmly press down to full seat the adhesive tape.