

Splash Guards - Front Pair (10-14 All)

Time Necessary: Approximately 30 minutes

Tools Required:

- Flathead screw driver
- Clip remover tool (optional)

Note: I recommending using the clip remover tool to help prevent damage to the clip.



Step 1: Clean surface of installation area.



Step 2: Using a flat head screw driver, loosen the middle pin in the two retaining clips from rocker panel.



Step 3: Using the clip remover tool pry both of the pin and retainer clips out.



Step 4: Align the back groove on the Splash Guard with the back of the rocker panel and then align the top with the fender overlap.



Step 5: Make sure the holes align with the holes in the rocker panel. Insert the pin/clip into each hole and press it in until it is completely flush.



Final Product Installed.



Installation Instructions written by AmericanMuscle customer Joey Campbell 12.25.13