

## Covercraft Deluxe Custom-Fit Car Cover - Pony Logo (10-14 GT, V6; 10-12 GT500)

**Time Necessary:** Under 30 mins.

### **Tools Required:**

- No tools required besides the cover itself



### **Prep:**

- Ensure that your vehicle has been thoroughly cleaned and free of dust/dirt as this may cause scratches on the vehicle surface when the cover is put on the car

### **Installation:**

1. Remove from packaging and unroll the cover on the vehicle to avoid getting any debris underneath the cover

***Pre-installation area - clean and dust free***



2. Place cover over antenna first



3. Slide mirror pouches over side mirrors next (this is important as the cover will not go on properly if you do not put these in before rolling over the front or back and slide it over the bottom of the car)





4. Next, roll cover to the front and back of the vehicle and use the elastic bottom to tuck it underneath.



5. The whole vehicle should now be covered. You can attach the optional rope to tie it down via the grommets if there is the potential for high wind located in the bottom middle of both sides of the cover. These grommets can also be used to lock the cover in place (lock not included).



### ***Post installation***

Installation Instructions written by AmericanMuscle customer A. Lara 12.18.13