

## Pony Package Style Lower Front Bumper Grille (05-09 V6)

### Tools required:

✓ None



### Installation Instructions:

1. Before installing, make sure that all 8 tabs that hold the grille in place have not been broken, or the grille may fall out.



2. The grille will be installed bottom first, so align all the bottom tabs into the bottom brackets of the bumper.



3. Place the top tabs into the top brackets and push firmly over each tab until they all snap into place.



4. Gently tug on each section of the grille to make sure it is secured into the bumper, and you are done!



Installation Instruction written by American Muscle customer Scott Musselwhite 1/08/13