

## **Center Console Arm Rest Pad Titanium Gray (87-93 All)**

**Install Time:** Approximately 5 min

**Tools Required:** Phillips Screwdriver



### **Removal Procedure:**

**Step 1:** Start by opening the center console arm rest.



**Step 2:** Next taking the Phillips screwdriver unscrew the screws holding the armrest pad onto the trim and Armrest bracket, There should be 4 total.

**Step 3:** Once removed the arm rest pad and trim should be free to pull off the bracket.

**Installation Procedure:**

**Step 1:** Take your new arm rest pad and align it with the trim.

**Step 2:** Once aligned Screw in the two top screws about half way so the pad can move around on the trim.



**Step 3:** Take the pad and trim and align it with the console bracket, The bracket should slide between the Arm rest pad and the trim.

**Step 4:** After bottom holes are lined up take the two remaining screws and screw them in, Not to tight remember it is plastic, and finish tightening the two top screws.



**Step 5:** Enjoy your new Arm rest pad



**Installation Instructions written by AmericanMuscle Customer Vance Clark 8.17.2014**