

Headlight Switch with Foglight (87-93 all)

Approx. time: 10 min

Tools: flathead screwdriver



Removal Procedure:

1. Take the flathead screwdriver and pry on one edge of the switch to remove it from its bezel.



2. After removed disconnect the two connectors on the back of the switch.



Installation Procedure:

1. Reconnect the two plugs on the back of your new headlight switch.



2. After plugging the two connectors back in turn on your key and test the headlight switch to make sure everything is in working condition.



3. Reinsert the switch back into the bezel by pushing until you hear a click, this will let you know that it is inserted correctly.



4. Enjoy your new and working headlight and foglight switch

Installation Instructions Written by AmericanMuscle Customer Vance Clarke 06.05.2014