

Dead Pedal Cover – (05-14 All)

(GT Logo, 5.0 Logo, Mustang Logo, GT/CS Logo)

TOOLS REQUIRED

- ✓ Hammer
- ✓ Small piece of cardboard or wood



Installation Time: Approximately 20 minutes

INSTALLATION:

1. Prior to installation, you'll want to ensure that the existing carpeted dead pedal is free of any debris or dirt. So give it a quick vacuum or brush off.



2. After you've removed the dead pedal cover from the box, find a small piece of cardboard or piece of wood of approximately the same dimensions as the side of the pedal cover.
3. Align the dead pedal cover in place (see picture below).
 - a. Place the small piece of wood or cardboard against the right edge of the pedal cover (red arrow)
 - b. While holding/pushing FIRMLY down on the dead pedal cover, tap the side of the dead pedal cover with a hammer (green arrow), using the piece of wood/cardboard to protect the dead pedal cover from damage from the hammer. Continue until the dead pedal cover is firmly seated and aligned top and side.



4. The Dead Pedal should be firmly in place now and you're done!



Installation Instructions written by AmericanMuscle Customer Michael Touw 9.8.2014