

Loading a Bama Custom Tune on your Mustang

1. Plug device into the OBDII port under the steering wheel, this will power up the device.
2. Once the device is powered up, select "Program Vehicle".
3. Then select the option for "Custom Tune"
4. You should then get a notice from SCT about this being a performance product that you need to select Yes to continue
5. Select the custom tune you'd like to load. It will look similar to "2006_V6_93R".
6. It will then prompt you to ask whether you want to adjust options. Select "Skip".
7. You'll be prompted to turn your key to the "On" position and back to "Off", without starting your motor.
8. Completely loading the tune may take up to 15 minutes, after which it is safe to remove the device from the OBDII port and start your engine.