

Mustang Bumper Inserts (79-04) - Installation Instructions



The below installation instructions work for the following products:

- **Matte Black Mustang Bumper Insert Letters (99-04 GT & V6)**
- **Stainless Steel Vinyl Bumper Inserts (94-98 Mustang GT & V6)**
- **Stainless Steel Vinyl Bumper Inserts (99-04 Mustang GT & V6)**
- **Stainless Steel Vinyl Bumper Inserts (03-04 Cobra)**
- **Black Vinyl Cobra Bumper Inserts Letters (03-04)**
- **Black Vinyl Cobra Bumper Insert Letters (96-98 & 01)**
- **Black Vinyl Mustang Bumper Insert Letters (94-98 GT & V6)**
- **Black Vinyl Mustang Bumper Insert Letters (99-04 GT & V6)**
- **Stainless Steel Vinyl Bumper Inserts (96-98 & 01 Cobra)**
- **White Reflective Vinyl Mustang Bumper Insert Letters (94-98 GT & V6)**
- **White Reflective Vinyl Mustang Bumper Insert Letters (99-04 GT & V6)**
- **Black Reflective Vinyl Mustang Bumper Insert Letters (99-04 GT & V6)**
- **Carbon Fiber Vinyl Mustang Bumper Insert Letters (94-98 GT & V6)**
- **Carbon Fiber Vinyl Mustang Bumper Insert Letters (99-04 GT & V6)**
- **Black Reflective Vinyl Mustang Bumper Insert Letters (94-98 GT & V6)**
- **Black Vinyl Mustang Bumper Insert Letters (87-93 GT & LX)**
- **Silver Vinyl Mustang Bumper Insert Letters (87-93 GT & LX)**
- **White Vinyl Mustang Bumper Insert Letters (87-93 GT & LX)**
- **Silver Vinyl Mustang Bumper Insert Letters (94-98 GT & V6)**
- **White Vinyl Mustang Bumper Insert Letters (94-98 GT & V6)**
- **Silver Vinyl Mustang Bumper Insert Letters (99-04 GT & V6)**
- **White Vinyl Mustang Bumper Insert Letters (99-04 GT & V6)**



Please read through the instructions carefully before starting this project. Take the time to get all the materials together as well as all the safety equipment.

Tools Required:

- Spray Bottle with dish soap & water mixture

Install:

1. Clean bumper well to ensure good adhesion of the letters. Fill a spray bottle with a mixture of water and dish soap. You can also use glass cleaner if you choose. Be sure to install letters out of direct sunlight.
2. Spray bumper with a generous amount of the soap and water mixture.



3. Peel letters from adhesive sheet and place them in the inserts on the bumper.



4. Once you have the letters properly aligned, push any air bubbles out towards the edges with your fingertip



Installation instructions provided by Manufacturer

Find more **how-tos, instructions** and **videos** at www.americanmuscle.com!