

Vividline Clear LED Rear Side Markers (15-19 All)

Installation Time: 30 Minutes

Tools Required:

Recommended but not required: Non-mar pry tool or flat head screwdriver

Installation Instructions:

- Start by looking under the rear bumper up to the backside of the marker light and unplug the light from the harness.



- Now reach towards the front of the car on the marker light and push the tab backwards to release the light.



- On the outside of the bumper, gently pull the front of the marker light out and then slide it forward to remove from bumper.
- Once unplugged, untwist the socket from the housing and plug it into the new marker light.
- Place marker light back in by sliding the rear in first and then clicking the front back in.
- Go back under the bumper and plug the new marker light in.
- Repeat for the other side of vehicle.



Installation Instructions Written by Bradley Davidson 07/10/2019