



Installation Instructions 2005-2007 Mustang Body Colored Door Mirror Inserts



Unpack the shipping carton and make sure that you have a drivers side and passenger side mirror insert. Each is marked on the foam pouch that the inserts are shipped in. Also in the package should be two packs of double sided adhesive and an alcohol wipe.

First wipe down both mirrors in the inset area and the inside of the mirror inserts with the alcohol wipe. Then apply 3 of the 4" strips of the double sided adhesive to each door mirror as shown in the picture. Remove the white backer to apply the adhesive strips, leave the backer that says VHB in place.



Peel off the backer from the double adhesive strips as shown in the picture.



Place the mirror insert over the mirror, being careful to align the top and bottom edges, and press firmly into place. The bond will take approximately 24 hours to reach full strength. Do not take your car through an automated car wash during that time period.



Your mirror inserts are molded from a high strength plastic and finished with automotive grade base coat, clear coat paint system. They can be treated the same as the body of your car as far as maintenance. Any clear coat safe wax, polish or car wash may be used to clean or polish them.

If you are not fully satisfied with your purchase of our door mirror inserts please contact us at **262-367-8254** or send us an e-mail at sales@midwestautogear.com. Also, if your are happy we would love to hear from you and have pictures of your car with our products. Watch our website at www.midwestautogear.com for new Mustang products coming soon.