

Polished Mustang Mass Air Sensor Cover (89-04) - Installation Instructions



The below installation instructions work for the following products:

- **Polished Mustang Mass Air Sensor Cover (89-04)**



Please read through the instructions carefully before starting this project. Take the time to get all the materials together as well as all the safety equipment.

Installation:

1. Be sure your engine is turned off and cooled down.
2. Locate your mass air flow sensor found on the passenger side of your car. It is just after your air cleaner housing.
3. On the top of the actual mass air flow housing is the black plastic cover that houses the electronics. This new cover is designed to attach to the black cover.
4. Install it with the slot opening towards the plug connector. Be sure the top surface of the black cover is clean and dry before securing it with the double sided tape provided in this kit.
5. In some cases it may be necessary to loosen the intake hose and back it away from the mass air flow sensor and then retighten.
6. To clean it use a soft cotton cloth and windex for best results.

Installation instructions provided by Manufacturer

Find more **how-tos**, **instructions** and **videos** at www.americanmuscle.com!